

Koldmount Acrylic Kit (454g Resin/32 Oz Hardener) - Mixing Instructions: Two parts resin to one part hardener. Mix for 30 seconds then pour over specimen. Cure time is about 30 minutes at room temperature.

Art. ID AR-AM1201
Unit each