

**Standard for 200 mm (8") diameter sieves - 300 µm, 315 µm, Mesh#50 (NIST Traceable)**

Art. ID	WHS-SS406
Unit	5 bottle set, 2,5 g per bottle
Deliverydetails	No Dangerous Good /not restricted

**Description**

Unique microsphere method of sieve calibration /// Mean aperture sizes traceable to NIST and NPL /// Measure over 1 million apertures per minute /// Typical calibration time of about 1 minute /// Method analyses over 80% of the sieve surface /// Accuracies and repeatabilities better than 1µm /// Results independent of sieve shaking method /// Single-shot bottles remove operator bias /// No need to send sieves away for calibration